



## Recommended Air Pressures

### Fox FLOAT RL ITch Switch Rear Shock

### 2002–03 Enduro FSR and S-Works Enduro

Rider Weight (pounds)	Air Pressure (PSI)
95 – 105	75
105 – 115	85
115 – 125	95
125 – 135	105
135 – 145	115
145 – 155	125
155 – 165	135
165 – 175	145
175 – 185	155
185 – 195	165
195 – 205	175
205 – 225	185
225 – 245	205
245 – 265	225

1. Sag is best set while in the long travel position.
2. Air pressure should ONLY be adjusted with the ITch Switch set to long travel.
3. If the shock is inflated with the switch set to the short mode, then one merely needs to turn it back to long travel and keep increasing the pressure until both chambers re-equalize. Then the pressure can be readjusted up or down to the desired setting.
4. This chart is provided as a guideline only. Actual settings may vary based upon terrain and rider preferences.
5. For more information, please contact your local Specialized Dealer.